






# Mid Modules & Connectors

## Standard 8" Profile



DYNAMIC CONVEYOR CORPORATION

Fill in \_\_ with 04, 06, 08, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 36, 42, 48, 54 or 60 for conveyor width

Modules / Connectors	Part Number	Functions / Features / Construction
17-1/2" Straight Extension 	EDNX__	<ul style="list-style-type: none"> <li>Connect between feed and drive modules to extend by 17-1/2"</li> <li>Requires 3' of belt</li> </ul>
6-1/2" Straight Connector 	JSNX__	<ul style="list-style-type: none"> <li>A straight connector will connect with another straight, 30° or 45° angle</li> <li>Requires 1' of belt</li> </ul>
30° Angle Connector 	JTNX__	<ul style="list-style-type: none"> <li>Use angles to change elevation (ascending or descending)</li> <li>Use a combination of angle connectors to achieve angles of various degrees</li> <li>Requires 1' of belt</li> </ul>
45° Angle Connector 	JFNX__	<ul style="list-style-type: none"> <li>Use angles to change elevation (ascending or descending)</li> <li>Use a combination of angle connectors to achieve angles of various degrees</li> <li>Requires 1' of belt</li> </ul>
Standard Radius Turn Modules 	R__45 R__60 R__90	<ul style="list-style-type: none"> <li>Standard profile height (8")</li> <li>Available in 4" - 24" widths</li> <li>Available in 45°, 60°, and 90° radius turns</li> <li>Connect between two modules to allow the conveyor to turn right or left at a given angle</li> <li>Use with External Mount Radius Turn Drive Module</li> <li>Requires Straight Extension Module(s) before changing direction (right or left)</li> <li>Requires Series 2400 Radius Flush Grid Belt</li> <li>Reversing options not available</li> </ul>
Retaining Wall Kit for Radius Turn Modules	KITR__45 KITR__60 KITR__90	<ul style="list-style-type: none"> <li>Use when additional wall height is required</li> <li>Adds 4" of height to existing 1-1/2" retaining wall</li> <li>One kit required per module</li> </ul>