






Accessory Options

Standard 8" Profile



DYNAMIC CONVEYOR CORPORATION

Fill in __ with 04, 06, 08, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 36, 42, 48, 54 or 60 for conveyor width

Accessory Options	Part Number	Functions / Features / Construction
Fan Module 	EDNX__-F TENX__-F	<ul style="list-style-type: none"> Use for cooling hot parts Fans are each 100 CFM, 15 watts, .13 amps Fits in 17-1/2" Straight Modules (EDNX__-F) and Feed End Modules (TENX__-F) Available in 6" to 60" wide modules
Conveyor Width	6" 8" 10" 12" 14" 16" 18" 20" 22" 24" 26" 28" 30" 36" 42" 48" 54" 60"	
Number of Fans	2 2 2 4 4 6 6 6 6 8 8 8 10 12 14 16 18 20	
CFM	200 200 200 400 400 600 600 600 600 800 800 800 1000 1200 1400 1600 1800 2000	
Metal Detector Module 	ACC7__	<ul style="list-style-type: none"> Detects steel, aluminum, copper, brass and stainless steel Commonly used to detect metal contamination Sensitivity based on the proximity of the metal contaminate to the belt Metal detection coil is integrated into a 17-1/2" standard module Upon detection of metal contaminate the conveyor stops and must be manually reset Includes manual reset Optional visual and/or audio alarms
E-Stop 	ACC517	<ul style="list-style-type: none"> True emergency stop with a reset button Plug and play design can be used with new or existing conveyors Emergency stop with mounting hardware User defined placement on conveyor Secondary emergency stops available in increments of 5' - 30')
AC/DC Indexing with Input Signal 	ACC538	<ul style="list-style-type: none"> Conveyor is normally off Upon receipt of 24 VDC input signal, the conveyor runs for a user defined time interval
Indexing for Variable Frequency Motor 	ELS538	<ul style="list-style-type: none"> Conveyor is normally off Upon receipt of 24 VDC input signal, the conveyor runs for a user defined time interval

Accessory Options

Standard 8" Profile



DYNAMIC CONVEYOR CORPORATION

Fill in __ with 04, 06, 08, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 36, 42, 48, 54 or 60 for conveyor width

Accessory Options	Part Number	Functions / Features / Construction
 <p>Electronic Photo Eye</p>	ACC525	<ul style="list-style-type: none"> • Plug and play design can be used with new or existing conveyors • Conveyor stops when photo eye beam is interrupted • Traditionally located at the end of conveyor to prevent parts from falling off
Reversing for Single Speed External Mount Motor	ELS546	<ul style="list-style-type: none"> • Conveyor reverses off a 24 VDC momentary/input signal or optional 110 VAC input signal • Conveyor runs until a 24 VDC input signal is received. Conveyor pauses for a moment, then runs in the opposite direction for the set amount of time. Conveyor then runs back in the original direction until it receives another 24 VDC input signal • Option used to reject bad parts off the back of the conveyor with a 24 VDC input signal from machine
Reversing for Single Speed Internal Mount Motor	ELS545	
Reversing for Variable Speed External Mount Motor	ELS555	
Reversing for Variable Speed Internal Mount Motor	ELS551	
Reversing for Variable Frequency External Mount Motor	ELS543	
 <p>Drop Zone Reinforcement Module</p>	EDNX__-D JSNX__-D TENX__-D	<ul style="list-style-type: none"> • Reinforces area that supports the belt in high impact applications • Available in 17-1/2" Straight Modules (EDNX__-D) • Available in 6-1/2" Straight Connector Modules (JSNX__-D) • Available in Feed End Modules (TENX__-D) • Impact area constructed of polyethylene